



In case of RCF:

Squawk 7600. Climb FL070 straight-ahead to intercept and proceed R095 LIS DVOR/DME. At 24 DME LIS DVOR/DME turn right to intercept and proceed R189 FTM DVOR/DME. When crossing R071 ESP DVOR/DME turn right to intercept and proceed R074 ESP DVOR/DME to ADSAD holding. After completing one holding pattern proceed on track 283° to PT422 (R167 14.4 DME CAS DVOR/DME). Turn right on track 026° to PESEX (R151 11.0DME CAS DVOR/DME) descending to 4000 ft to perform another LOC approach.

PT422 RDL corrected.

THIS PAGE INTENTIONALLY LEFT BLANK