


STANDARD DEPARTURE CHART -
INSTRUMENT (SID) - ICAO

MADEIRA INFORMATION 130.355
MADEIRA TOWER 118.355
MADEIRA APPROACH 119.605

MADEIRA / LPMA
RWY 05
IRKID 6N, MADAT 6N, ORTIS 6N
SNT 6E, SNT 6N, TABOM 6N



New CS and FREQ. Chart redrawn.

STANDARD INSTRUMENT DEPARTURE (SID) RWY 05

RUNWAY 05				
Designator	Route	After Take-off		Remarks
		Climb to ALT / FL	Contact	
IRKID6N	Proceed on MAG Track 087 after passing ABM FUN DVOR/DME (RDL178) and above 1500FT QHN turn left to MAG Track 337, keeping FUN DVOR/DME left hand: above 3000FT QNH intercept and proceed on RDL 321 FUN DVOR/DME to IRKID	FL060	Madeira Approach 119.605MHZ	Do not overshoot RDL 321 FUN DVOR/DME to the South
MADAT6N	Intercept and proceed on RDL212 FUN DVOR/DME; after 11NM FUN DVOR/DME or above 3500FT QNH turn right to intercept and proceed on RDL 214 FUN DVOR/DME to MADAT	FL060		
ORTIS6N	Intercept and proceed on RDL180 FUN DVOR/DME to GOSGA - ORTIS	FL060		
SANTO6E (SNT6E)	Proceed on MAG Track 087 after passing ABM FUN DVOR/DME (RDL178) and above 1500FT QHN and crossing the 04NM FUN DVOR/DME proceed on QDM038 PST NDB; intercept and proceed on RDL085 FUN DVOR/DME; Intercept and proceed on RDL183 to SNT DVOR/DME	FL060		To be used pending traffic conditions and for traffic landing at LPPS
SANTO6N (SNT6N)	Proceed on MAG Track 087 after passing ABM FUN DVOR/DME (RDL178) and crossing the 4NM arc FUN DVOR/DME and not below 1500FT QNH proceed on QDM038 to PST NDB; proceed to SNT DVOR/DME	FL060		To be used pending traffic conditions and for traffic landing LPPS
TABOM6N	Intercept and proceed on RDL 163 FUN DVOR/DME to TABOM	FL060		